

Track Tractors

- Slide heavy wall tubes (torpedos) into receiving holes in track frame
- On the inside of the track put the $\frac{1}{2}$ " bolt in the tubes
- Attach the tank frames and bolt tight
- Tanks go on either way with rinse tank front or back
- Install tank bung at any time
- For installation of 600 gal tanks onto the brackets, put the bung in first, leave arches loose on the bracket, put the tanks on the frames, get the hoop bolts started, and tighten arch bolts and hoop bolts

Once the tank frames are bolted tight to the heavy wall tubing they **will not** slide into the track. Be sure to have them positioned where you want them prior to tightening the $\frac{7}{8}$ " bolts.