

Installing with lifting hook

The lifting hook we have added to our brackets for front duals has greatly improved the ease of installation. The hook has several different adjustments depending on bracket, tank, and plumbing configuration. Once the balance point is found simply position the bracket close to the tractor and lift on the hook using a ¾" or heavier chain. The bracket will then be free to twist or rotate enough to get the bolts in place.

CAUTION!!

Please be safe, as safety is always first. **Never** get under a bracket when installing! We advise using two people to mount the brackets to insure safety and prevent damage.